



# Protectakote

Protectakote is a single component, ready-to-use, anti-slip coating enhanced with polyurethane performance for ultimate toughness. The course profile textured surface is ideal for interior floors, factory work-stations, walkways, stairs, ramps, vehicles and other areas where a flexible, durable and long lasting anti-slip surface is important. Protectakote is ready-to use, easy to apply by brush, roller or spray and is available in a variety of colours as well as a smooth version for maintenance coats.

## PRODUCT USES

- Protectakote is suitable for interior and exterior use, however for extended life in extreme outdoor conditions Protectakote UVR is recommended.
- Protectakote can be applied to: metal, concrete, wood, fibre-glass, PVC, rubber, glazed tiles and previously painted surfaces.
- Protectakote can be used to create safe, anti-slip areas on:
  - Light industrial and commercial floors.
  - Walkways, stair edges and bridges.
  - Wheelchair access ramps, emergency exits, fire escapes and around machinery.
  - Protectakote can be used as an automotive coating to protect load beds, tail lifts, chassis and wheel-arches of 4x4's, trucks, commercial vehicles and trailers.
  - Smooth finish is ideal as a protective coating for indoor flooring applications and can also be used to refurbish textured areas without adding more profile.

## COVERAGE

- 4m<sup>2</sup> per litre per coat. Applied in a 2 coat application. Giving an overall coverage of 2 m<sup>2</sup> per litre.
- Three coats are recommended for high wear areas.
- Coverage will vary depending on the porosity and profile of the surface.

## SURFACE PREPARATION

Substrates differ significantly, and so all new applications should be tested first.

Ensure all substrates are thoroughly clean, sound, dry and free from any contaminants such as dirt, rust, salt, algae and grease. Protectakote exhibits good adhesion to most primers. All non-porous substrates with the exception of painted surfaces require a primer. Zest Polyurethanes supplies suitable primers for all substrates - consult us for our range of primers.

- **Steel:** Abrade surface lightly and remove any surface rust or mill scale by sanding, wire brushing, with a chipping hammer or sandblasting. Prime with Protectakote 2K Metal Primer, as per instructions, within 30 minutes.
- **Galvanized Iron:** Clean away grease and dirt with a suitable galvanized iron cleaner until a water break-free surface is attained. Rinse well with water and allow to dry. Prime with a suitable etch or galvanized iron primer the same day as the surface was prepared to avoid re-contamination and flash rust.
- **Aluminium:** Abrade to fresh metal, clean well using detergent. Prime with Protectakote 2K Metal Primer as per instructions within 30 minutes. For applications where pooling of water is expected, a specific waterproof primer for aluminium is required such as Protectakote Universal Epoxy Primer.

## FINISH

- Available in a smooth finish or textured anti-slip finish
- 

## COLOURS

- A wide variety of colours

## ADVANTAGES

- Single component – ready to use direct from can.
- Easy to apply – no skilled labour required.
- Fast drying - Drying time can be accelerated if necessary.
- Polyurethane performance – ultimate toughness.
- Course rubber crumb texture.
- Flexible – won't chip, flake or peel even at low temperatures.
- Excellent resistance to abrasion, chemicals and solvents.
- Weather resistant.
- Prevents rust and corrosion.
- Excellent capacity to repel water.
- High adhesion to most surfaces including metal, concrete, wood, fibreglass, PVC and rubber.
- Can be overcoated and easily repaired.
- Will not taint water or food once cured.

- **Concrete:** Allow new concrete at least 28 days to cure. Old and new cement or concrete surfaces must be acid-etched, rinsed well and dried. Prime with Duram Duraprime epoxy primer as per instructions if damp or oil contaminated.
- **Wood:** Abrade, clean and allow to dry before applying Protectakote directly. Dilute the first coat with 10% xylene to aid penetration.
- **Fibre-glass:** Abrade well, solvent wipe and apply Protectakote directly onto the surface.
- **PVC:** Abrade and clean well using xylene. Allow to dry before applying Protectakote directly. An adhesion test is recommended prior to use.
- **Rubber (nitrile or chloropene):** Clean well using detergent or cleaning solvent such as xylene. Allow to dry. An adhesion test is recommended prior to use.
- **Glazed tiles:** Glazed tiles must be cleaned and treated with a suitable primer (an organosilane) for adhesion of Protectakote.
- **Gloss Paints and Varnish:** Abrade with a scouring pad or medium grit sandpaper to remove all gloss. Wipe with a solvent, allow to dry and apply Protectakote directly.
- **Motor Vehicles and Painted Metal:** Remove heavy dirt and rust. Previously painted surfaces need to be lightly abraded using a scouring pad or medium grit sandpaper to remove all gloss. Wipe with a solvent, allow to dry and apply Protectakote directly.

## APPLICATION

- Take care when opening as contents may be under pressure.
- Wear safety goggles and protective gloves.
- Ensure substrates have been prepared, tests for adhesion completed and areas not to be coated have been masked off.
- Stir well before use using a flat paddle.
- Always apply a test patch of Protectakote to ensure the substrate has been properly prepared and primed. Check adhesion of the coating by cutting a small X in the coating using a utility knife. Firmly apply a piece of packaging tape over the centre of the X cut, then pull off with a fast snap. The adhesion is suitable if no significant coating is removed beyond the X cut. If the coating fails this test, then additional surface preparation is required – repeat the surface preparation steps above.
- **Brush-on:** Protectakote should be “laid” onto the surface with a brush (do not brush backwards and forwards as with an enamel paint). Two coats will result in a final dry film thickness of 0,6mm to 0,8mm. Second or subsequent coats should be applied at right angles to the previous coat. Intercoat time is approximately 2 hours, when touch dry, depending on ambient conditions.
- **Roller:** If applied with a stipple roller, application is quicker and the final texture rougher with greater anti-slip characteristics. Follow same instructions as per Brush-on. Intercoat time is approximately 2 hours, when touch dry, depending on ambient conditions.
- **Spray-On:** Dilute Protectakote with 10% xylene. Fill spray gun pot, and attach airline providing a minimum pressure of 5 bar. Protectakote should be applied in thin coats to prevent “mudcracking” during drying. Depending on the application, two or more coats can be applied. Ensure each coat is dry before applying the next coat. Intercoat time is approximately 2 hours, when touch dry, depending on ambient conditions.
- **Curing time:** Protectakote cures with atmospheric moisture. The coating will be touch dry in about 2 to 4 hours and allowing light traffic after 9 hours. Full strength and chemical resistance is achieved in 4 to 7 days, but normally the coating can be put to use after 24 hours.
- **Accelerated cure:** In areas of low atmospheric moisture, temperature or when shorter curing times are required, an accelerator can be added. This is available from Zest Polyurethanes (Pty) Ltd.
- **Overcoating and repair:** Protectakote can easily be repaired or overcoated. The old surface should be well cleaned and then abraded by wire brush or sandpaper, and damaged surfaces must be cut out to provide an area without loose edges. Follow application instructions. If Protectakote is left for more than 24 hours after coating, it should be abraded before recoating to aid intercoat adhesion. If correctly done, Protectakote provides a seamless repair.

## CLEANING

- **Uncured Protectakote:** Can be cleaned in its uncured state using a solvent such as xylene.
- **Cured Protectakote:** Can be removed with MEK (Methyl Ethyl Ketone), paint stripper or by mechanical means.
- Remove any spills immediately as Protectakote is very difficult to remove once cured.
- Use hot soapy water to clean the cured coating.

## IMPORTANT

- Please read all instructions carefully before starting the project.
- Proper surface preparation is critical for successful application of Protectakote.
- Do not clean surfaces with lacquer thinners.

- Do not mix with water, turps, thinners or any solvent containing water or alcohol. Alcohol will prevent Protectakote from curing, while water will cause it to foam and cure in the can.
- Once opened, use Protectakote within 3 hours, or 2 hours if an accelerator is used.
- Protect from moisture and do not expose to temperatures above 50 °C.

#### SAFETY PRECAUTIONS

- **Solvents are toxic: Avoid inhalation** – may cause coughing, lung irritation, headaches, dizziness or nausea.
- **Protectakote is highly flammable in wet state: Use in a well-ventilated area to prevent the build-up of flammable solvent vapours. Observe all fire precautions and do not smoke, use flames or naked lights during application.**
- **Extinguishing media: Keep extinguishing powder, CO<sub>2</sub> or halones close during application.**
- **Wear safety goggles and protective gloves. Avoid contact with skin and eyes.**
- **Spray Application: Areas where spraying takes place should be clean and well ventilated. Use suitable respiratory safety equipment and protective clothing.**
- **Spillage/leakage: Do not empty into drains. Keep away from sources of ignition. Take up with absorbent material. Fill into sealable containers. Dispose of containers in accordance with local waste legislation in your country.**
- **Skin contact: Remove contaminated clothing and wash skin thoroughly with soap and water.**
- **Eye contact: Flush immediately with water for 10-15 minutes and contact a physician.**
- **Respiratory problems: Remove affected person to fresh air immediately and contact a physician.**
- **Not for internal consumption. If swallowed, contact a doctor or poison control centre immediately. Do not induce vomiting. Drink water.**
- **Keep out of reach of children.**

## TECHNICAL DATA

Pack size	1L & 4L Brush-On, 1L Spray-On & 4L DIY Kit		
Finish	Textured & Smooth finish		
Colour	Range of standard colours		
No of components	Single Pack		
Drying schedule @ 425 microns wet	@ 10°C	@ 20°C	@ 30°C
Tack free time	6 hours	3 hours	2 hours 15 min
Light traffic	18 hours	9 hours	6 hours 45 min
Full traffic	72 hours	36 hours	27 hours
Full cure	4-7 days depending on conditions		
To recoat	Minimum: 6 hours	2 hours 30 min	2 hours 15 min
	Maximum before re-preparation of the surface becomes necessary: 24 hours		
Volume Solids:	73% ±2%		
VOC Content	≤250g/litre as supplied		
Film tensile strength at break	16MPa		
Film elongation at break	225%		
Service Temperature	-30°C to 110°C		
Application temperature	10°C to 30°C (An accelerator is available for lower temperatures) Application to substrates in excess of 35°C is not advisable due to the defects and porosity.		
potential for surface			
Flexibility	Excellent		
Weathering	Excellent, not colour fast, may fade		
Density	1,03g/cm <sup>3</sup> (brush version)		
Viscosity	80 to 110ku (brush version)		
Soluble in	Xylene		
Flash point	27°C		
Explosive limits	Lower: 2,1 % by vol Upper: 11, 5% by vol		
Thermal decomposition	No decomposition below initial boiling point		
Hazardous reactions	Exothermic reaction with amines, alcohols, acids and alkalis in uncured state. Reacts with water forming CO <sub>2</sub> . Closed containers may rupture owing to increase of pressure. Open pressurized containers carefully, to release pressure.		
Toxicity	Toxic in uncured state		
Thinning/clean up	Xylene		
Shelf Life	18 months unopened. Store indoors at 5 to 35°C.		
Storage Conditions	Cool, dry area below 25°C		

*Technical details above are provided in good faith. We are an ISO 9001: 2008 registered company and our products are manufactured to the highest standards using raw materials of superior quality. Consequently we believe in the quality of our products and will willingly replace any product in the unlikely event of a quality related performance failure. Whilst we are confident in guaranteeing the quality of our products, we cannot however accept any liability for performance failure due to the incorrect application of our products. Correct application is critical to the successful performance of our products and as this process falls outside of our control we are unable to cover the application under our product performance warranty. Where there are doubts, it is recommended that the user conduct their own suitability tests before use. To retain sheen and colour consistency of your paint, always make sure that the batch numbers are the same on all paint containers that you purchase. Updated: March 2015 (this supercedes all previous publications)*